



Instructions for using your bin latch

The 'SafeWaste' bin lid latch is designed to keep the lid of your landfill or recycling bin safely closed, avoiding any spilling of the content of your bin.

Please follow the instructions on the next page to attach your lid latch.

To open the lid to place more items inside, simply pull the tab of the latch down (Step 5) to release the hook from the side of the bin, then reattach the hook once items are inside.



Minimum bin weights

At the kerbside, our trucks use mechanical arms to lift and tip your latched bin upside down to empty it. For the weight of your bin contents to force the latch open, you need at least 2.3 kg of recyclables or landfill waste inside it. For small amounts of waste, please wait until your bin is fuller to place it at the kerbside for collection, or remove the latch for emptying.

To attach your bin latch follow these simple steps.

If you have any questions, feel free to phone us on 06 759 6060.



STEP 1.

Wetting the SafeWaste with water first makes installation very easy.



STEP 2.

Bring SafeWaste under the bin lid handle so that the hook is facing down.



STEP 3.

Bring the rounded end of SafeWaste across the top of the bin lid handle.



STEP 4.

Thread the rounded end of SafeWaste through the rectangular ring.



STEP 5.

Pull the SafeWaste so the hook catches on the side of the bin.

